# WISCONSIN<br/>BUILDING<br/>ENERGY CODESUMMARY OF KEY<br/>RESIDENTIAL ENERGY<br/>CODE REQUIREMENTS

The 2009 IECC was adopted with amendments in Wisconsin as the Uniform Dwelling Code and went into effect on **January 1, 2016**. This document summarizes changes to the building envelope-related requirements in the updated code for Wisconsin.

## CODE CHANGE HIGHLIGHTS -

- Footnote f of Table 322.31-1 allows for R-20 and R-21 wall insulation to be installed in 2x6 cavities.
- Building envelope tightness and insulation installation can be acceptable with a visual inspection when items in Table 332.37 are field-verified.
- The code implements a building-envelope compliance pathway for projects using required levels of heating efficiencies.



### **BUILDING ENVELOPE REQUIREMENTS**

		CHANGE	SUMMARY	DWELLINGS USING Lower Efficiency Appliances*	
<b>CODE PATH</b>	SPS CODE SECTION	CLIMATE ZONE 6	CLIMATE ZONE 7	CLIMATE ZONE 6 & 7	
Prescriptive	322.31-1 – Wood Frame Wall	R-20 or 13 + 5 / U-0.057	R-21 / U-0.057	R-21 or R-19 + 5 ci / U-0.057	
	322.31-1 – Ceilings	R-49 / U-0.026	R-49 / U-0.026	R-49 / U-0.026	
	322.31-1 – Basement Walls	R-19 or R-15 ci / U-0.050	R-19 or R-15 ci / U-0.050	R-19 or R-15 ci / U-0.045	
	322.31-1 – Crawl Space Walls	R-13 or R-10 ci / U-0.065	R-13 or R-10 ci / U-0.065	R-19 or R-15 ci / U-0.045	
	322.31-1 – Fenestration	U-0.35	U-0.35	U-0.30	
	DUCT LEAKAGE		AIR LEAKAGE		
MEASUREMEN	IT CFM25 / 10	0 SQ. FT.	ALL CLIMATE ZONES		
Rough-in			7 ACH50		
Post-construct	tion 8				

Note: All R-values are minimums and U-factors maximums. \* Efficiency levels noted in Table 322.31-3.

### ACCESS MORE INFORMATION ON THE WISCONSIN BUILDING ENERGY CODE HERE:

 $http://docs.legis.wisconsin.gov/code/admin_code/sps/safety_and_buildings_and_environment/320_325/322.pdf\#page=4$ 



This summary is offered for informational purposes only. It does not purport to be an exhaustive analysis of code changes or provide advice that will ensure guaranteed compliance with any energy code provision. Please consult with local authorities before finalizing your installation plans.

# ENERGY-EFFICIENT, COST-EFFECTIVE CONSTRUCTION WITH FIBERGLASS AND MINERAL WOOL INSULATION



As code levels advance, **keep informed about innovative practices** to meet or exceed code requirements using cost-effective fiberglass and mineral wool insulation.

The following resources in the table below are just a subset of the many guides available from the **Insulation Institute** to help you achieve new performance requirements with proven approaches.

#### **INSULATION INSTITUTE RESOURCES**

Air Leakage	As states adopt more stringent energy codes, some builders may experience challenges meeting new mandatory air leakage requirements. Fiberglass and mineral wool insulation is the low-cost solution for homebuilders to meet or surpass code air leakage rate requirements of 3 or 5 air changes per hour depending on climate zone. For homeowners an airtight building envelope results in energy savings and increased thermal comfort. https://insulationinstitute.org/wp-content/uploads/2018/05/N090-5-Air-Sealing-Locations-for-New-Homes.pdf
Ducts Buried Within Ceiling Insulation	Deeply buried ducts in attics is an easy way to lower energy code compliance costs for builders using the simulated energy performance path. Homeowners can benefit from energy savings realized from lower-capacity, lower-cost HVAC systems.
	https://insulationinstitute.org/wp-content/uploads/2019/03/N087-Buried-Ducts-The- newest-way-to-uncover-savings.pdf
Proper Installation of Insulation	Grade I installation delivers superior energy efficiency and is increasingly required by state energy codes. Insulation installation jobs that fail to meet Grade I criteria can mean construction delays due to callbacks, HERS rating penalties, and failed code inspections. Grade I installation is readily achievable by following basic guidelines as recommended by manufacturers. NAIMA offers free online training for installers. www.grade1insulation.org
Unvented Attics Using Fiberglass and Mineral Wool Insulation	Unvented attics can be constructed by installing fiberglass or mineral wool insulation below the roof deck instead of using more costly materials like spray foam. In addition, fiberglass and mineral wool insulation products are green certified and do not carry recommended occupancy restrictions due to product off-gassing after installation. Starting with the 2018 IRC, this practice is outlined in detail within the code. Homeowners benefit from lower construction costs and the use of a safe product.
	https://insulationinstitute.org/wp-content/uploads/2018/05/ BuildingUnventedAtticAssemblies-N089.pdf
-	Ducts Buried Within Ceiling Insulation Proper Installation of Insulation Unvented Attics Using Fiberglass and Mineral

https://www.energycodes.gov/technical-assistance/training/courses/ 2015-iecc-energy-rating-index-eri-compliance-alternative

### Get the Facts for a Stronger Business

Learn more about fiberglass and mineral wool insulation at InsulationInstitute.org

### NAIMA

MANUFACTURERS ASSOCIATION P.O. Box 1906 • Alexandria, VA 22313 InsulationInstitute.org • 703.684.0084